



SEPARATE NO-VOLT SUPPLY: REMOVE LINK BETWEEN 1 ON RC & 96 ON OL AND 5 ON RC & A1 ON RC. CONNECT SEPARATE SUPPLY TO 96 ON OL & A1 ON RC.

LINE & NEUTRAL CONTROL REMOVE LINK BETWEEN A1 & 5 ON RC AND CONNECT NEUTRAL TO A1 ON RC.

PRESS TO RUN REMOVE WHITE LINK (13 ON FC-61 ON RC) REMOVE BROWN LINK (13 ON RC-61 ON FC)