



PRESS TO RUN
REMOVE WHITE LINK (13 ON FC-61 ON RC)
REMOVE BROWN LINK (13 ON RC-61 ON FC)

SEPERATE NO-VOLT SUPPLY: REMOVE LINK BETWEEN
2 ON FC & 96 ON OL AND 6 ON OL & A1 ON RC.
CONNECT SEPERATE SUPPLY TO 96 ON OL & A1 ON RC.